




The quick start up/shutdown guide is not a substitute for reading the manual; the manual contains detailed information and instructions that you must be aware of and follow in order to maintain the equipment properly and use it safely. Remember to record the date of purchase and model number in your manual.

Items Included:




Items needed: (not included)









- Grease
- Garden hose, 50 ft. (15 m) or less
- Safety goggles (indirect vented type)
- Pump Saver™




USE OUTDOORS - AVOID CARBON MONOXIDE POISONING - (SEE MANUAL)





Start Up



Outdoor Use Only



Shutdown



WARNING! Use pressure washer only with specifically designated battery packs. Use of any other battery packs could create a risk of injury and fire.


QUICK START UP / SHUTDOWN GUIDE





WARNING! Risk of eye injury. Spray could splash back or propel objects resulting in serious injury.

- Always wear indirect vented (chemical splash) safety goggles when using or near this product.
- Always wear protective clothing such as long-sleeved shirts, long pants and closed-toed shoes.

Handle and Accessory Tray Attachment



Connect 2-Pin Connector




Copyright © 2020. All rights reserved. CRAFTSMAN® is a registered trademark of Stanley Black & Decker, Inc., used under license. No part of this material may be reproduced or transmitted in any form without the express written permission of Briggs & Stratton Corporation.

Every effort has been made to ensure that the information in this document is accurate and correct. However, we reserve the right to alter or otherwise improve the product and this document at any time without prior notice and without incurring obligation.



Elementos incluidos:




- Grasa
- Manguera de jardín, 50 pies (15 m) o menos
- Gafas de seguridad (tipo de ventilación indirecta)
- Pump Saver™










MOFLE

apúntelo en dirección opuesta a la casa



Instale alarmas de monóxido de carbono en el interior de su casa. Sin alarmas de monóxido de carbono en funcionamiento, es posible que no se dé cuenta de que se está intoxicando y muriendo debido a una intoxicación por monóxido de carbono.



Arranque



**Sólo para uso
en exteriores**




Apagado




- Siempre use gafas de seguridad con ventilación indirecta (salpicaduras de sustancias químicas) cuando utilice este producto o esté cerca del mismo. (Las gafas de seguridad no brindan una protección total).
- Siempre use ropa protectora como camisa de manga larga, pantalones largos y calzado cerrado.

Aditamento de mango y bandeja para accesorios



Conecte el conector de dos clavijas



¡ADVERTENCIA! Utilice lavadora a presión sólo con paquetesde baterías específicamente diseñados. El uso decualquier otro paquete de baterías puede producirriesgo de incendio y lesiones.

Copyright © 2020. Reservados todos los derechos. CRAFTSMAN® es una marca registrada de Stanley Black & Decker, Inc., usa abajo licencia. Queda prohibida la reproducción total o parcial de este material, sin el permiso previo y por escrito de Briggs & Stratton Corporation.

Se ha realizado el máximo esfuerzo para reunir en este manual la información más precisa y actualizada. No obstante, nos reservamos el derecho de modificar o mejorar de cualquier otra forma el producto y este documento en cualquier momento y sin previo aviso, y sin incurrir en ninguna obligación.

(888) 331-4569

WWW.CRAFTSMAN.COM